



All instructions refer to the seated position

The Denbigh D07 high back mesh chair is a stylish, practical task chair, which offers a combination of comfort, good posture, and practicality, and can be customised to the individual users' requirements.

1. The lever on the right-hand side, operates the gas strut to adjust the chair seat height. Twist up to activate and then release in the desired position.
2. The lever on the left-hand side, operates the chair reclining action. This action is synchronised which means that the back angle increases more quickly than the seat angle when reclining backwards. To operate twist the lever up and lean back. There should be a little resistance to your body weight (see instruction 2). The chair can now be used in this floating mode or locked in fixed predetermined positions by twisting the lever back. The mechanism also has an 'anti-shock' feature which prevents the back springing forward when the lever is operated. To bring the chair forward from a locked position, twist the lever, recline backwards a little and then bring your weight forwards - the back will come with you.
3. On the left-hand side of the seat pad towards the front is a button which operates the seat slide. This can be pushed in to release the mechanism, which allows you to adjust the length of the seat.
4. The hand wheel underneath the chair in the centre allows the user to adjust the chair to suit their body weight. Turning the hand wheel clockwise makes the reclining action firmer and turning counter clockwise makes it less firm. For optimum comfort it is important to adjust the tension control properly to suit the weight of the individual.
5. The chair is fitted with an adjustable lumbar support. This is operated by twisting the levers on the back of the support to the desired amount of firmness.
6. The back-rest height is adjusted on a ratchet mechanism. Gradually lift the back a ratchet at a time until you have your preferred height. When you exceed the highest ratchet, the back will drop back down to the lowest position to enable you to reset.
7. The height adjustable fold down arms have dual functionality and are height adjustable by using the silver button on the outside of the arm. Simply push the button in to lift the arm and release the button to lock in position. To fold the arm down (towards the back of the chair) there is a silver spigot located at the top of the silver disc on the outside of the arm. Push the spigot in and roll the arm backwards. To return the arm to upright, reverse this procedure.
8. The optional fitted head rest is height adjustable on a ratchet and can also be twisted fore and aft.
9. The chair is designed to accommodate users weighing up to 150kg.
10. All chairs are built to comply with BS5459 (1990) Part 2.

A wide range of accessories including a headrest, different arm and base options, can help customise the chair to suit individual preferences.